


Mounting instruction for electronic chuck and thermostat.

How to use TVS heating element with timer-function



By pressing button (4) you can switch the heater on and off.


Afterwards you can by means of the buttons (5) regulate the temperature up and down. A red light will appear in the control lamps (3) when you regulate it up and it will be turned off when you regulate it down. The temperature level will be between 6 and 60 degrees Celsius.

If you activate the timer function (2) when the heater is on, it will continue at the predefined temperature for two hours and afterwards be shut off entirely. Then there will be a green light in the control lamp timer function (1).

If you activate the timer function (2) when the heater it shut off, there will appear a green light in the control lamp timer (1) and the heater will be switch on after two hours.

ANTI-FREEZE – function

If the temperature in the room is below 5-7 degrees the ANTI-FREEZE function of the heater will be activated. The heater will automatically be switched on and will keep the radiator above 5-7 degrees. During this process the control lamp in the middle will blink red.



TVS
Designradiatorer